

<b>List of escalator outages recorded Cutty Sark</b>		Period 1 2017	
Asset	Detail	actual start	actual end

<b>List of escalator outages recorded Cutty Sark</b>		Period 2 2017	
Asset	Detail	actual start	actual end

<b>List of escalator outages recorded Cutty Sark</b>		Period 3 2017	
Asset	Detail	actual start	actual end

CUS 1	CUTTY SARK STATION - ESCALATOR No. 1	21-Jun-17 18:58	21-Jun-17 21:19
-------	--------------------------------------	-----------------	-----------------

<b>List of escalator outages recorded Cutty Sark</b>		Period 4 2017	
Asset	Detail	actual start	actual end

CUS 1	Station Building - Cutty Sark	12-Jul-17 17:37	12-Jul-17 18:10
-------	-------------------------------	-----------------	-----------------

<b>List of escalator outages recorded Cutty Sark</b>		Period 5 2017	
Asset	Detail	actual start	actual end

<b>List of escalator outages recorded Cutty Sark</b>		Period 6 2017	
Asset	Detail	actual start	actual end

CUS 2	Cutty Sark Station - Escalator No. 2	26-Aug-17 17:10	26-Aug-17 18:47
-------	--------------------------------------	-----------------	-----------------

<b>List of escalator outages recorded Cutty Sark</b>		Period 7 2017	
Asset	Detail	actual start	actual end

<b>List of escalator outages recorded Cutty Sark</b>		Period 8 2017	
Asset	Detail	actual start	actual end

CUS 1	Cutty Sark Station - Escalator No. 1	05-Nov-17 11:45	05-Nov-17 12:39
CUS 2	Cutty Sark Station - Escalator No. 2	22-Oct-17 20:58	23-Oct-17 04:33
CUS 2	Cutty Sark Station - Escalator No. 2	24-Oct-17 22:18	25-Oct-17 17:00
CUS 2	Cutty Sark Station - Escalator No. 2	04-Nov-17 19:12	04-Nov-17 19:18

<b>List of escalator outages recorded Cutty Sark</b>		<b>Period 9 2017</b>	
<b>Asset</b>	<b>Detail</b>	<b>actual start</b>	<b>actual end</b>
CUS 2	Cutty Sark Station - Escalator No. 2	15-Nov-17 05:15	15-Nov-17 23:00
CUS 2	Cutty Sark Station - Escalator No. 2	15-Nov-17 06:50	15-Nov-17 23:00
CUS 4	CUS:CUS Escalator 4 OOS - OTIS have been called out	16-Nov-17 18:41	16-Nov-17 20:16

<b>List of escalator outages recorded Cutty Sark</b>		<b>Period 10 2017</b>	
<b>Asset</b>	<b>Detail</b>	<b>actual start</b>	<b>actual end</b>
CUS 2	Cutty Sark Station - Escalator No. 2	22-Dec-17 10:30	22-Dec-17 13:12
CUS 2	Cutty Sark Station - Escalator No. 2	31-Dec-17 09:05	31-Dec-17 17:35
CUS 2	Cutty Sark Station - Escalator No. 2	06-Jan-18 15:20	06-Jan-18 17:49

<b>List of escalator outages recorded Cutty Sark</b>		<b>Period 11 2017</b>	
<b>Asset</b>	<b>Detail</b>	<b>actual start</b>	<b>actual end</b>
CUS 3	CUS:CUS - Escalator 3 stopped: Break ware fault display. Request to use esc 4 as the up escalator.	24-Jan-18 16:20	25-Jan-18 01:00
CUS 4	CUS:CUS - Escalator 4 - OOS - Two teeth broken off comb	03-Feb-18 18:47	04-Feb-18 00:10

<b>List of escalator outages recorded Cutty Sark</b>		<b>Period 12 2017</b>	
<b>Asset</b>	<b>Detail</b>	<b>actual start</b>	<b>actual end</b>

<b>List of escalator outages recorded Cutty Sark</b>		<b>Period 13 2017</b>	
<b>Asset</b>	<b>Detail</b>	<b>actual start</b>	<b>actual end</b>